

WORK PRO[®] **L I F T E R S**




LIFTING SYSTEMS

OPERATING INSTRUCTIONS

FOR MODELS:

LW 142D /DY
LW 150D /DY
LW 155D /DY
LW 185D /DY
LW 265D /DY
LW 290D /DY
LW 330D



Version 1.0



LIFTING SYSTEMS

OPERATING INSTRUCTIONS

FOR MODELS:

LW 142D /DY

LW 150D /DY

LW 155D /DY

LW 185D /DY

LW 265D /DY

LW 290D /DY

LW 330D

IMPORTANT

Carefully read and understand all points and aspects of this manual. Lifting loads irresponsibly can cause lethal accidents. Installation of lifting systems and proper use are only responsibility of the user.

It is recommended to attach this manual with the tower system used.

In case of doubt, consult the technical department of Work Lifters.

CONTENT

WARNING ICONS.....	5
RULES AND SAFETY USE	6
PARTS IDENTIFICATION	11
HOW TO USE. STEP BY STEP.....	12
STANDARDS TAKEN INTO ACCOUNT.....	14
WIRE DRIVE SYSTEM	15
DYNSYS SYSTEM	16
TRANSPORT.....	17
With forklift.....	17
With truck or container.	17
DGUV V17/18 REGULATION.....	18
SPECIFICATIONS	19
<i>DECLARATION OF CONFORMITY</i>	20
DGUV MARK.....	21

CONTACT

Internet: www.equipson.es



e-mail: support@equipson.es

ILLUSTRATION INDEX

Figure 1.....	6
Figure 2.....	6
Figure 3.....	6
Figure 4.....	6
Figure 5.....	7
Figure 6.....	7
Figure 7.....	7
Figure 8.....	7
Figure 9.....	8
Figure 10.....	8
Figure 11.....	8

Figure 12.....	8
Figure 13.....	9
Figure 14.....	9
Figure 15.....	9
Figure 16.....	9
Figure 17.....	10
Figure 18.....	10
Figure 19.....	11
Figure 20.....	12
Figure 21.....	12
Figure 22.....	12
Figure 23.....	12
Figure 24.....	13
Figure 25.....	13
Figure 26.....	13
Figure 27.....	14
Figure 28.....	15
Figure 29.....	15
Figure 30.....	16
Figure 31.....	17
Figure 32.....	17
Figure 33.....	19

WARNING ICONS



RULES AND SAFETY USE




Figure 1

Keep hands and fingers away from moving parts of the tower.




Figure 3

Do not lift the tower without proper leveling. To lift a load, the tower must always be stabilized. The wheels must not touch the ground.




Figure 2

Not charge the tower without the stabilizers legs.




Figure 4

Place the tower on a stable surface.

If the ground has a low degree of compaction (earth, gravel, etc..) consult the section of load data.




Figure 5

Do not use the tower on inclined surfaces that require pieces to level the tower.




Figure 7

Never move a load without leveling the tower before.



Figure 6

Before placing a load, make sure that the load never exceeds the maximum allowed. Consult the section of load data




Figure 8

Do not use ladders on the tower or leaning against it.




Figure 9

Not grease and lubricate the mechanism of the winch and the pulleys of the masts.




Figure 11

Do not stand under the load. The load must be secured to the tower in order to prevent that the load cannot fall down.




Figure 10

Not allowed to lift people or animals.




Figure 12

Verify that the tower is beyond the reach of power lines.

The tower is not electrically insulated and can transmit currents of power lines.

On the following table is recommended the average length between the highest part of the structure and the power lines.

Voltage	Min. distance	
	Meters	Feet
Between phases		
0 to 230v	1.5	4.92
230v to 400v	2.8	9.19
400v to 50Kv	3.4	11.15
50Kv to 200Kv	4.9	16.08
200Kv to 350Kv	6.5	21.33
350Kv to 500Kv	8.2	26.90
500Kv to 750Kv	11.3	37.07
750Kv to 1000Kv	14.2	46.59

Figure 13

Not use the tower as welding mass.

If necessary, use the grounding placed on the base.




Figure 14

Not lift a load if there is danger of collision. Take at least 1.5 meters on any direction to lift the load safely.




Figure 15

The tower can be used outdoor if the wind speed is low and If it doesn't put the installation in risk. The installation is always under responsibility of the owner.




Figure 16

Do not use the tower as a support of banners or another type of decoration with strong wind that can destabilize the tower and make it falls.




Figure 17

Do not lift structures that require more than one tower at different speeds.

$V1 \neq V2$ No lift

$V1 = V2$ Ok




Figure 18

The structure must be levelled correctly. If not, the structure can fall.

Always $h1 = h2$

PARTS IDENTIFICATION




Figure 19

- | | | | |
|---|-------------------|----|--------------|
| 1 | Bubble level | 6 | Lock system |
| 2 | Winch | 7 | Level handle |
| 3 | Cable | 8 | Baseplate |
| 4 | Wire drive system | 9 | Leg |
| 5 | Profile | 10 | Wheel |

HOW TO USE. STEP BY STEP

- See Figure 26 in this section to understand the security system function.




Figure 20

Fix and secure the stabilizers legs to the base.




Figure 21

Level the tower. Ensure that the wheels never contact the ground.




Figure 22

Turn the security of the first profile from horizontal position (blocked) to vertical (opened).




Figure 23

Move the handle of the winch to lift the tower.

When the section reaches its limit, lock with the security system and unlock the following security system to lift the next mast. Do the same operation until you reach the required height.




Figure 24

All security systems must be in locked position.




Figure 25

To lower the load: Unlock the first security system. Turn the winch while maintaining the other hand unlocking security system.




Figure 26

Different positions and purpose of security system:

BLOCKED: Once the profile is in the correct position, turn it to block the profile.

UNBLOCKED: Unblock the profile to elevate and lower the profile.

STANDARDS TAKEN INTO ACCOUNT




Figure 27

WIRE DRIVE SYSTEM

WIRE DRIVE is a new and important feature developed to help prevent undesired and dangerous cable crosses in the drum of the winch, making easier the cable roll up/unroll process, and avoiding crashing or fraying that could reduce the useful life of the cable or (in the worst case) its breakage.




Figure 28

WIRE DRIVE is responsible for directing the cable across the drum of the winch and accumulate it in successive and continuous turns without creating problematic crossings.




Figure 29

DYNSYS SYSTEM



The lifters that incorporate the DYNYSYS system are named as LW xxx DY:

LW 142 DY - LW 150 DY – LW 155 DY – LW 185 DY – LW 265 DY – LW 290 DY

Dynsys system is an optional solution for the control of the maximum load in lifting systems.

Dynsys limits the maximum load of the tower avoiding to raise a higher load to the specified. For more information about maximum load, consult the load chart.

In case of raising a load higher than the maximum, Dynsys detects the increase in load and prevents it from being raised, allowing only the descent of the load.

DYNSYS system works as a preventive maintenance element. In case the tower has some internal damage and forces the system to operate in a forced manner, DYNYSYS system will limit its use, preventing that the internal components (cable, pulleys, profiles, etc. ...) may deteriorate further. If this happens, contact the technical department or your nearest distributor.

The system allows the disassembly of the crank, thus allowing the blocking of the tower. In this way it is avoided that personnel outside the installation can manipulate the tower by raising or lowering it. Only the two Allen screws should be removed.




Figure 30

TRANSPORT

To the transport of the towers:

- Verify that the stabilizers legs are securely fixed to the tower in the transport and they cannot be released.
- Check that all sections are locked.

With forklift

To transport the towers with a machine type forklift the AW 100 accessory is necessary. Follow the instructions of the machine operator transport manual. Take into account the height of what is transported. Avoid sudden turns and braking.




Figure 31

Detail of transport with forklift.

With truck or container.

To transport the tower by truck or container always tie the tower by two points. Use ratchets not less than 250 kg of force.

Place ratchets so that the tower cannot move by inertia in curves or sudden braking.




Figure 32

Detail tower place and shape holding.

DGUV V17/18 REGULATION. Explanation

DGUV V17/18 is a norm that regulates the stage and production elements in the entertainment industry. Lifting equipment and rigging are part of this norm and cover structures and other technical elements.

Adopt **DGUV V17/18** is totally voluntary (except in Germany) but its adoption is required by insurance companies and indeed is becoming a norm in the industry

The application of this norm on lifter towers is vital because, in theaters, stages, etc., are used to move loads above artists, technical staff, etc... and in some cases, above viewers, representing a potential risk of fall.

NORM DGUV V17/18. Fields of application

This standard is oriented in two ways:

On the one hand, lifting towers adopt designs and materials in order to achieve a high degree of safety in quantities such as supported load, equilibrium, resistance to friction, etc.

Thus lifter towers **EQUIPSON DGUV V17/18** certified, they assure the user that have passed strict controls during design, choice of materials or load checks and effort.

On the other hand, in order to achieve optimal performance with these units, it is recommended, and a responsible use of the unit, (meeting basic norms such as obey the maximum load or balance), periodic maintenance which It must be carried out by expert technicians, checking the condition of the steel cable and winch, the functioning of the security pins and the folding/unfolding of all sections.

All the above tests are only mandatory in those countries with specific regulations on the matter, applied through regulations or laws. As manufacturers, we recommend passing all tests in order to prevent damage and ensure proper operation of lift systems.

SPECIFICATIONS

- Same values For LWxxxDY lifters (DYNSSYS system)

Model	LW142D	LW150D	LW155D	LW185D	LW265D	LW290D	LW330D
Minimum Height (m)	1,59	1.9	1,72	1,72	1,80	1,84	1,29
(ft)	5,22	6,23	5,64	5,64	5,91	6,04	4,23
Base Folded Width (mm)	360	360	360	460	460	460	140
(ft)	1,18	1,18	1,18	1,51	1,51	1,51	0,46
Base Folded Length (mm)	360	360	360	460	460	460	140
(ft)	1,18	1,18	1,18	1,51	1,51	1,51	0,46
Maximum Height (m)	4,05	5	5,3	5,3	6,5	6,6	3,3
(ft)	13,29	16,40	17,39	17,39	21,33	21,65	10,83
Unfolded diameter (m)	1,88	2,06	2,06	2,06	2,52	2,58	1,64
(ft)	6,17	6,76	6,76	6,76	8,27	8,46	5,38
Minimum load capacity (Kg)	25	25	25	25	25	25	25
(Lb)	55,12	55,12	55,12	55,12	55,12	55,12	55,12
Max. load (Kg)	100	100	150	210	220	290	100
(Lb)	220,46	220,46	330,69	462,97	485,02	639,34	220,46
Net weight (Kg)	28,8	32,8	43,4	73,2	93,4	136,8	21
(Lb)	63,49	72,31	95,68	161,38	205,91	301,59	46,3
Winch (Kg)	450	450	350	500	500	900	450
(Lb)	992,08	992,08	771,62	1102,31	1102,31	1984,16	992,08
Noise emissions (dB)	70	70	70	72	72	75	68

Figure 33



DECLARATION OF CONFORMITY

The tower lifters described complies with all the specific requirements of Directive 2006/42 / EC of the European Parliament and of the Council of 17 May 2006 on the Machinery Directive.

The tower lifters described meet all the specific requirements in DGUV V17/18

Manufacturer: EQUIPSON, S.A.

Person responsible of the technical data:

José Vila Ortiz

Address:

Avda. El Saler, 14 – Pol. Ind. L´Alteró
46460 – Silla – Valencia (Spain)

Description:

Upside load lifter

LW 142D /DY

MAX. LOAD: 100 kg

LW 150D /DY

MAX. LOAD: 100 kg

LW 155D /DY

MAX. LOAD: 150 kg

LW 185D /DY

MAX. LOAD: 210 kg

LW 265D /DY

MAX. LOAD: 220 kg

LW 290D /DY

MAX. LOAD: 290 kg

LW 330D

MAX. LOAD: 100 kg



A handwritten signature in blue ink, appearing to read "J. Vila Ortiz".

José Vila Ortiz, December 2017

DGUV MARK

NUMERO DE SERIE:	SERIAL NUMBER:	LAUFENDE NUMMER:

Primer test en fábrica	First test in factory.	Erstprüfung im Werk.
Fecha/Date/Datum	Testado por/Tested by/Prüfer	

Examen a los cuatro años.	Four years test	UVV Prüfung (alle 4Jahre)
Fecha/Date/Datum	Testado por/Tested by/Prüfer	

Examen anual a partir
del cuarto año.

Annual test after the fourth
year.

UVV Jährlicher Test nach
dem vierten Jahr.

Fecha/Date/Datum	Testado por/Tested by/Prüfer
Fecha/Date/Datum	Testado por/Tested by/Prüfer
Fecha/Date/Datum	Testado por/Tested by/Prüfer
Fecha/Date/Datum	Testado por/Tested by/Prüfer



Av. Saler nº 14 Polígono. Ind. L`Alteró. Silla 46460 VALENCIA-SPAIN
Tel: +34 96 121 63 01
www.workpro.es