


AP 302

Quick Guide – Version 1.0



300W+300W @ 4Ω

Stereo & bridge modes

Soft start function

AC 115V/230V 50/60Hz (selectable)

Amplifier 300W+300W @ 4Ω

SAFETY INSTRUCTIONS


- Use the closed QR code to download the last user manual version from our website.
- Don't use this device close to the water or high humidity places. Clean only with dry cloth.
- Don't install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Protect the power cord from being walked on or pinched.
- Only use attachments/accessories specified by AUDIOMUSC
- Unplug this device during lightning storms or when unused for long periods of time.



51EAP302

AP 302

Guía rápida – Version 1.0



300W+300W @ 4Ω

Modos estéreo y Bridge

Función Soft start

AC 115V/230V 50/60Hz (seleccionable)

Amplificador 300W+300W @ 4Ω

INSTRUCCIONES DE SEGURIDAD

- Use el Código QR adjunto para descargar la última versión del manual de usuario desde nuestro sitio web.
- No use este dispositivo cerca del agua o zonas altamente húmedas. A la hora de limpiarlo, utilice un paño seco.
- No instale el dispositivo cerca de ninguna fuente de calor o fuego tales como calefactores, estufas o incluso amplificadores que produzcan calor.
- Proteja el cable de ser pinzado o pisado.
- Únicamente utilice accesorios especificados por AUDIOMUSIC
- Desenchufe el dispositivo si no va a ser utilizado en largos periodos de tiempo.



51EAP302