


MOVIED SPOT 100

Quick Guide – Version 1.0



LEDs: 1x 80W Ultra-bright White LED + 12x RGB 3-in-1 SMD 5050 LED

Control modes: DMX512, Audio, Auto, Master/Slave.

Channels DMX: 12 & 14 channels

Gobo wheel: 9 static gobos + spot

Color wheel: 9 colors + white

3 facet prism with rotation

80 W Moving Head LED Spot


SAFETY INSTRUCTIONS

- Use the closed QR code to download the last user manual version from our website.
- Before connect the device, check your country safety regulations.
- Don't use this device close to the water or high humidity places. Clean only with dry cloth.
- Don't install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat. Make certain that the equipment is always installed so that is cooled and can't overheat.
- Protect the power cord from being walked on or pinched.
- Only use attachments/accessories specified by MARK.
- Unplug this device during lightning storms or when unused for long periods of time.
- The technical service is required when the device has been damaged in any way, such as power supply cord or plug is damaged, liquid has been spilled or objects have fallen into the device, doesn't operate normally or has been dropped.



MOVILED SPOT 100

Guía rápida – Versión 1.0



LEDs: 1x 80 LED Blanco ultra-brillante + 12x LEDs RGB 3-en-1 SMD 5050.

Modos de control: DMX512, Audio, Auto y Master/Slave.

Canales DMX: 12 y 14 canales

Rueda de gobos: 9 gobos estáticos + spot

Rueda de colores: 9 colores + blanco

Prisma de 3 caras con rotación.

Cabeza Móvil Spot LED 80W

INSTRUCCIONES DE SEGURIDAD

- Use el Código QR adjunto para descargar la última versión del manual de usuario desde nuestro sitio web.
- Respete las instrucciones de seguridad de su país cuando instales este dispositivo
- No use este dispositivo cerca del agua o zonas altamente húmedas. A la hora de limpiarlo, utilice un paño seco.
- No instale el dispositivo cerca de ninguna fuente de calor o fuego tales como calefactores, estufas o incluso amplificadores que produzcan calor. Asegúrese de que, una vez instalado el dispositivo, esté en un lugar fresco y seco.
- Proteja el cable de alimentación para no ser pisado o manipulado.
- Únicamente utilice accesorios especificados por MARK
- Desenchufe el dispositivo si no va a ser utilizado en largos periodos de tiempo.
- El dispositivo será reparado por el servicio técnico oficial cuando esté dañado, tal como el cable este deteriorado o el conector esté estropeado, así como si el dispositivo ha sufrido contacto con líquidos o no opera correctamente.

