



WAC 4 (W/B)

Quick Guide – Version 1.0



Touch control panel & APPs launcher

4" display/Android 11

2GB RAM / 32GB ROM

Available in white & black colour

Default Password: 123456

**** Uploaded WORKPRO® control APPs and audio players**

4" Touch control panel & APPs launcher

SAFETY INSTRUCTIONS

- Use the closed QR code to download the last user manual version from our website.
- Don't install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Only use attachments/accessories specified by WORK PRO
- Unplug this device during lightning storms or when unused for long periods of time.



28LED725



28LED727



WAC 4 (W/B)

Guía rápida – Versión 1.0



Panel de control touch y launcher de aplicaciones

Pantalla de 4" /Android 11

2GB RAM / 32GB ROM

Disponible en colores blanco y negro

Password por defecto: 123456

**** APPs de control WORKPRO® y reproductores de audio, precargados**

Pantalla de control touch 4" y launcher de APPs

INSTRUCCIONES DE SEGURIDAD

- Use el Código QR adjunto para descargar la última versión del manual de usuario desde nuestro sitio web.
- No instale el dispositivo cerca de ninguna fuente de calor o fuego tales como calefactores, estufas o incluso amplificadores que produzcan calor.
- Únicamente utilice accesorios especificados por WORK PRO
- Desenchufe el dispositivo si no va a ser utilizado en largos periodos de tiempo.



28LED725



28LED727