



WTS 256

Load: 260 kg. Height: 6.30 m.



WTS 375

Load: 380 kg. Height: 5.09 m.



WTS 506

Load: 510 kg. Height: 6.08 m.



WTS 708

Load: 700 kg. Height: 8.13 m.



WTS 905

Load: 900 kg. Height: 5.2 m.



WTS 1206

Load: 1200 kg. Height: 6 m.



WORKi LIFTERS
LW 10
Stand for follow spot



WORKi LIFTERS
LW 130
Lighting stand



WORKi LIFTERS
LW 330 D
Load: 100 Kg. Ø 35. Height: 3,3 m. Weight: 21 Kg. Wire Drive



WORKi LIFTERS
LW 142 D
Load: 100 Kg. Ø 35 mm. Height 4,05 m. Weight 28 Kg. Wire Drive



WORKi LIFTERS
LW 150 D
Load: 100 Kg. Ø 35. Height : 5 m. Weight: 32 Kg. Wire Drive



WORKi LIFTERS
LW 155 D
Load: 150 Kg. Ø 35. Height: 5,3 m. Weight: 43 Kg. Wire Drive



LW 185 D

Load: 210 Kg. Ø 35. Height : 5,3 m. Weight: 73 Kg. Wire Drive



LW 265 D

Load: 220 Kg. Ø 40. Height: 6,5 m. Weight: 93 Kg. Wire Drive



LW 290 D

Load: 290 Kg. Ø 50. Height: 6,6 m. Weight: 136 Kg. Wire Drive



AWS 401

Accessory for WTS 256, WTS 375, WTS 506 lifters. For line array



AWS 501

Accessory for WTS 1206, WTS 905, WTS 708 lifters. For line array



AWS 403

Accessory for WTS 256, WTS 375 lifters. For line array



WORKi
LIFTERS
AWS 402

Accessory for WTS 506 lifter. For line array



WORKi
LIFTERS
AWS 502

Accessory for WTS 1206, WTS 905, WTS 708 lifters. For line array



WORKi
LIFTERS
AWS 301

Accessory for WTS 1206, WTS 905, WTS 708 lifters. For truss



WORKi
LIFTERS
AWS 302

Accessory for WTS 506, WTS 375, WTS 256 lifters. For truss



WORKi
LIFTERS
AW 155

Support bar for truss. Adjustable width. Diameter: 55 mm male



WORKi
LIFTERS
AW 137

Support bars with adjustable width for truss



WORK
LIFTERS
AW 140

Support bar for truss. Adjustable width. Diameter: 40 mm male



WORK
LIFTERS
AW 150

Support bar for truss. Adjustable width. Diameter: 50 mm male



WORK
LIFTERS
AW 135

Support bar for truss. Adjustable width. Diameter: 35 mm male



WORK
LIFTERS
AW 215

Support bars with fixed width for truss



WORK
LIFTERS
AW 237

Support bars with fixed width for truss



WORK
LIFTERS
AW 235

Support bar for truss. Diameter: 35 mm male



WORK
LIFTERS
AW 240

Support bar for truss. Adjustable width. Diameter: 40 mm male



WORK
LIFTERS
AW 250

Support bar for truss. Adjustable width. Diameter: 50 mm male



WORK
LIFTERS
AW 255

Support bar for truss. Adjustable width. Diameter: 55 mm male



WORK
LIFTERS
AW 335

Support bar for truss. Diameter: 35 mm male



WORK
LIFTERS
AW 355

Support bar for truss. Diameter: 55 mm male



WORK
LIFTERS
AW 340

Support bar for truss. Diameter: 40 mm male




AW 10

Parallel truss support bar. Diameter: 35 mm male




AW 11

Parallel truss supports bars for truss




AW 12

Parallel truss support bar. Diameter: 40 mm male




AW 13

Parallel truss support bar. Diameter: 55 mm male




AW 535

Support bar for 6 lighting spots. Diameter: 35 mm male




AW 537

Horizontal bars for spots



AW 540

Support bar for 6 lighting spots. Diameter: 40 mm male



AW 550

Support bar for 6 lighting spots. Diameter: 50 mm male



AW 555

Support bar for 6 lighting spots. Diameter: 55 mm male