



NEO AIR
Audio Wireless Solutions






Integrated system solutions

The AIR range offers 5-inch satellites capable of master/slave operation (NEO 5 AIR). To provide additional low-end reinforcement, the NEO S8 AIR subwoofer features the same configuration versatility. For tabletop applications, the AIR DOCK base station is also available.

The master unit receives signals via Bluetooth or a line-level mini-jack. Users can select the radio channel for all zone elements using 4 rear-panel micro-switches. Up to 16 independent channels are available to manage as many separate zones.

Primary Bluetooth communication

Specially designed to use Bluetooth as the primary system communication. Once the source device is connected to the master unit, the signal is broadcast across the entire zone. A mini-jack input is also provided for users who prefer a wired line-level source






Multi-zone signal management

The NEO AIR range is the ideal solution for installations where a wired signal distribution is not feasible or desired. This versatile system is built around the master/slave concept: each NEO AIR unit can be configured as a master or a slave, allowing for a setup with one master and as many slaves as the installation requires.

Simply connect your audio source to the master unit, which then wirelessly broadcasts the signal to all synchronized slaves throughout the venue, ensuring a clean and efficient setup without the need for complex cabling.





WORKPRO
SOUND FOR BUSINESS

www.workpro.es