EN

LASER HOME BALL

Safety Instructions

WARNING

Please read the instructions carefully which includes important information about the installation, operation and maintenance.

Please keep this User Manual for future consultation. If you sell the fixture to another user, be sure that they also receive this instruction booklet.

Unpack and check carefully there is no transportation damage before using the fixture.

It's important to ground the yellow/green conductor to earth in order to avoid electric shock.

Disconnect main power before servicing and maintenance.

Maximum ambient temperature is Ta : 40℃. Don't operate it where the temperature is higher than this.

In the event of serious operating problem, stop using the fixture immediately. Never try to repair the fixture by yourself. Repairs carried out by unskilled people can lead to damage or malfunction. Please contact the nearest authorized technical assistance center. Always use the same type spare parts.

Do not connect the device to any dimmer pack.

EN

Do not touch any wire during operation and there might be a hazard of electric shock.

To prevent or reduce the risk of electrical shock or fire, do not expose the fixture to rain or moisture.

The housing must be replaced if they are visibly damaged.

Do not look directly at the LED light beam while the fixture is on.

There are no user serviceable parts inside the fixture. Do not open the housing or attempt any repairs by yourself. In the unlikely event your fixture may require service, please contact your nearest dealer.

Due to the magnifying type lens, please keep the lens out of contact with direct sunlight. Direct sunlight can cause heat to build up inside of the unit, which will seriously damage unit.

Specifications

Main supply	AC 95-220V, 50/60 Hz
Consumption	20W
Light source	LEDs: 3 x3W RGB
Functions	Auto-run, Sound, Internal rotation
Motor	Synchronous motor
Effects	Round dots, circles, strobe effects, program select color & change
Dimensions	190 x 190 x 115 mm
Weight	0,5 kg

ES

AMS®

LASER HOME BALL

1. Instrucciones de seguridad

AVISO

Por favor, lea las instrucciones cuidadosamente, incluyen información importante sobre la instalación, manejo y mantenimiento de la unidad

Por favor, conserve este manual de uso para futuras referencias junto con la unidad.

Desembale y compruebe cuidadosamente que no se han producido daños durante el transporte antes de usar la unidad.

Es importante conectar el cable amarillo/verde a tierra con el fin de prevenir descargas eléctricas.

Desconecte la alimentación antes de repararlo o limpiarlo.

La temperatura ambiente máxima es Ta: 40ºC. No opere la unidad en lugares con una temperatura superior.

En caso de serios problemas de uso, deje de usar la unidad de inmediato. Nunca trate de repararla por si mismo. Las reparaciones llevadas a cabo por personal no autorizado, pueden ocasionar daños o mal funcionamiento. Por favor, contacte con su distribuidor para obtener asistencia técnica. Use siempre los repuestos autorizados.

No conecte la unidad a un dimmer.

No toque el cableado mientras esté conectado para evitar descargas eléctricas

Para prevenir el riesgo de descargas eléctricas o fuego, no exponga la unidad a la lluvia o la humedad.

La carcasa externa debe ser sustituida si se aprecian daños

No mire directamente la luz producida por los LED mientras la unidad está en marcha.

No hay elementos de control para el usuario en el interior. No abra la carcasa o trate de repararla por usted mismo. En el caso de que necesite ser reparada, contacte con su distribuidor.

Debido a la precisión de las lentes, por favor, evite que entren en contacto con la luz solar directa.

Especificaciones

Alimentación	AC 95-220V, 50/60 Hz
Consumo	20W
Fuente lumínica	LEDs:3 x3W RGB
Funciones	Auto-run, Audio, Rotación interna
Motor	Motor síncrono
Efecto	Aros rotativos, círculos, efecto strobo
Dimensiones	190 x 190 x 115 mm
Peso	0,5 kg